

FOLEY SPECIALIST VEHICLES



Overland Checklist



Overland Checklist

When Overlanding the main priority is choosing a vehicle that is simple to maintain in the territory that it will be used. Non-electronic engines such as the 300 Tdi are most popular for Overlanders. The Td5 engines are used, but can create problems in the management systems which cannot always be solved easily without the correct software.

The most popular body types are the 110" Station wagon and the 110" Hardtop. The 130" is also a popular vehicle, giving a bit extra space, followed by the 90" and the Discovery. Almost 90% of all the Overland vehicles that we build, prepare, sell or hire are 300 Tdi powered.

On average, a typical London to Cape Town trip covers 25,000 miles and our aim is to give you every mile as trouble free as possible.

"Safe Travels"

Safety & Security:

- Roll Bars (Internal and/or External)
- Grills on Rear Windows
- Floor Safe
- Rear Windows Blanked Off (S/W 110)
- Stainless Steel Door Locks
- 1 Kg Fire Extinguisher
- Internal Security Grill
- Steel Cubby Box between Front Seats
- Fuel Cut Off Switch (Hidden)

General Equipment:

- Roof Rack (Heavy Duty Steel Galvanised)
- Rear Ladder
- Roof Rack fitted with Non Slip Deck Board
- Heavy Duty Bull Bar (For A/C & Non A/C)
- Water Tank 40l with Tap
- Extra Fuel Tank 40l
- Rear Storage System (110 S/Wagon)
- Rear Storage System & Bed Set Up (110 Hard Top)
- Sand Ladders (Steel)
- Mount for Sand Ladders
- Split Charge Dual Batteries
- Battery Cut Off
- Internal Lights
- External Lights
- Front Spot Lights
- Rear Work Light
- Hi Lift Jack
- Hi Lift Jack Mount Kit
- Jerry Can Holders (Roof Rack)
- Jerry Can Side Lockers (40l 110 Hard Tops)
- Side Runners/Steps
- Rear Step
- Heavy Duty Front Winch Bumper
- Winch (Choice of Budget or Top End)

General Equipment Continued:

- Rear Seats 60/40, Lowered and Moved Back (Extra Headroom)
- Canvas Seat Covers
- Radio CD iPod
- Rear Tow Pin (Rear Cross Member)
- Front Tow Point
- Steering Guard (Alloy Plate Type)
- Steering Guard (Steel Bar Type)
- Front Diff Guard
- Snorkel / Raised Air Intake
- Chequer Plate: Wings
 - Bonnet
 - Sills
 - Rear 1/4s
- Rear Swing Away (Mantec)
- Wolf Rims (Heavy Duty)
- Standard 6th Spare Wheel (Lightweight)
- BF Goodrich Tyres 235/85 AT

Suspension & Bushes

- Heavy Duty Front Springs
- Heavy Duty Rear Springs
- Inner Rear Springs
- Anti Roll Bars, Front & Rear
- Standard Front Shocks
- Twin Rear Shocks
- Standard Genuine Landrover Bushes

Camping Equipment

- Roof Tent 1.4m (Eezi Awn) T-Top Extra
- Awning 3m (Eezi Awn)
- Stainless Steel Table (Front Runner)
- Stainless Steel Side Table
- Fridge 40l (Engel)
- Table Runners for Roof Rack (Front Runner)
- Storage Boxes
- 2 Ring Gas Cooker

Loose Extras

- Tow Strap
- Fan Spanner
- Tyre Levers
- Heavy Duty Wheel Brace 27mm
- Brass Radiator Plug
- Jerry Cans
- Water Cans
- Haynes Workshop Manual
- Puncture Repair Kit
- £500 Spares Kit